

WIRE SPLICE and REPAIR KIT

FOUR WIRE KIT

SP4C

WIRE SIZE #14-#12-#10

INSTRUCTIONS

A HEAT SOURCE IS REQUIRED
WIRES MUST BE CLEAN

1. Slip melt tubing over wires.
 2. Crimp connectors onto wires.
 3. Center tubing over connector and heat, beginning at the center and working towards ends.
 4. Seal is complete when tube shrinks to shape and sealant flows from ends of tube.
- If using torch flame:
KEEP HEAT SOURCE MOVING.
DO NOT OVER HEAT.

