

End Suction Pumps

ITEM NO.	SUCTION	1½	2	3	3	3	1½	2	3	4	6	2	2	3	4														
	DISCHARGE	1	1½	2	2½	2	1	1½	2	3	4	1	1½	2	3														
	MAX IMPELLER	6	6	6	7	8	8	8	8	8	8	10	10	10	10														
	IMPELLER BORE	¾	¾	1¼	¾	1¼	¾	1¼	¾	1¼	¾	1¼	¾	1¼	¾	1¼													
008	IMPELLER WEAR RING SUCTION SIDE ADAPTER SIDE	A A	B A	B A	C A	C A	D A	D A	C A	C A	B A	B A	B A	C A	C A	E A	E A	F A	B A	B B	B A	B B	C A	C B	E A	E B			
014	SLEEVE	A	A	B	A	B	A	B	A	B	A	B	A	B	A	B	B	B	A	B	A	B	A	B	A	B	A	B	
025	CASING RING	A	B	B	C	C	D	D	C	C	B	B	B	B	C	C	E	E	F	B	B	B	B	C	C	E	E		
027	ADAPTER RING	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	A	B	A	B	A	B	A	B	A	B
032	IMPELLER KEY	A	A	B	A	B	A	B	A	B	A	B	A	B	A	B	B	B	B	A	B	A	B	A	B	A	B	A	B
071	MOTOR ADAPTER 143-184 JM 213-215 JM 254-256 JM 284-326 JM	A B - -	A B - -	- B C D	- - C D	E F - H	- - G H	E F - H	- - G H	E F - H	- - G H	E F - H	- - G H	E F - H	- - G H	- - G H	- - G H	- - G H	- - G H	I J - L	- - K L	I J - L	- - K L	I J - L	- - K L	I J - L	- - K L		
089	SEAL	A	A	B	A	B	A	B	A	B	A	B	A	B	A	B	B	B	A	B	A	B	A	B	A	B	A	B	

Interchangability Chart

Model 3122
Bulletin 3000

DEMING®

www.cranepumps.com

End Suction Pumps

ITEM NO.	SUCTION	5		6		8		3		4		6	
	DISCHARGE	4		4		6		2		3		4	
	MAX IMPELLER	10		10		10		13		13		13	
	IMPELLER BORE	3/8	1/4	3/8	1/4	3/8	1/4	3/8	1/4	3/8	1/4	3/8	1/4
008	IMPELLER WEAR RING SUCTION SIDE ADAPTER SIDE	H B	H B	I B	I B	J B	J B	G C	G C	E C	E C	H C	H C
014	SLEEVE	A	B	A	B	A	B	A	B	A	B	A	B
025	CASING RING	H	H	I	I	J	J	G	G	E	E	H	H
027	ADAPTER RING	C	C	C	C	C	C	D	D	D	D	D	D
032	IMPELLER KEY	A	B	A	B	A	B	A	B	A	B	A	B
071	MOTOR ADAPTER 143-184 JM 213-215 JM 254-256 JM 284-365 JM	I J - -	- K L	I - K L	- J K L	I - J K L	- J K L	- M N O	- M N O	- M N O	- M N O	- M N O	- M N O
089	SEAL	A	B	A	B	A	B	A	B	A	B	A	B

SECTION 3120
PAGE 14
DATE 10/18

CRANE®

A Crane Co. Company

PUMPS & SYSTEMS

USA: (937) 778-8947 • Canada: (905) 457-6223 • International: (937) 615-3598